

Apply a screen guard without air bubbles

- Make sure it is relatively free of dust where you're doing it, it's the SMALL dust grains that so easily gets caught under the film. A tip that I've never tried myself is to do it in the bathroom just have you have taken a shower since then the moisture in the air would have caught all those tiny little particle. And of course clean hands!
- Use gloves if you're worried about getting fingerprints on the display or the display film during application.
- Align the screen guard with all the protection foil on at first, to make sure you get it just right since not all display guards are created equal.
- Wipe the display THOROUGHLY, preferably with some sort of wet screen cleaning to remove any grease spots and stuff. Finish with a dry lint-free cloth, wipe along with the display to remove any "wet marks".
- All display guards have some sort of "pull tab" so that one can distinguish between the protective film **(A)** from the display guard **(B)**, loosen maybe a centimeter of the plastic cover and fold it back against the display guard.
- Align the display cover gently on the display, watch your fingers if you do not use any kind of gloves.
- Press the display guard with fingers of one hand so that it "sticks" to the display.
- Then pull off the plastic protective film while you press the display cover with a small rubber squeegee **(C)** or a visa card (works just as well with mastercard), do it like a centimeter at the time so you can press out any air bubbles while doing it.
- Just make sure the placement is good, it is possible to adjust it a bit while you're doing it
- If the display guard has an upper protective plastic **(D)**, remove this layer.

